

Where in the file system the configuration template files are stored?

Q

Where in the file system the configuration template files are stored?

A

Configuration templates are stored in XML files named "<device type>_Templates.xml", for example: "netIC_Templates.xml"

These XML files can be found in "%ProgramData%\Hilscher GmbH\netX Configuration Tool\Project" folder, where %ProgramData% points to different paths for the different versions of the Windows operating system as shown on the examples below.

Windows XP: C:\Documents and Settings\All Users\Application Data\Hilscher GmbH\netX Configuration Tool\Project

Windows Vista, Windows 7, Windows 8: C:\ProgramData\Hilscher GmbH\netX Configuration Tool\Project

See also...

- Where in the file system the configuration template files are stored?